

Lens/Screen Selector Charts for TC-201/TC-301

TC-201

Nikon F3-Series Cameras

Lens	Screen	A/L	B	C	D	E	G1	G2	G3	G4	H1	H2	H3	H4	J	K/P	M	R	T	U	
Fisheye	6mm 1/2.8	●	○	○	○	○		○					○		○	●		○	●		
	8mm 1/2.8	●	○			○		○				○			○	●		○	●		
	16mm 1/2.8	●	○			○		○				○			○	●		○	●		
Wideangle	13mm 1/5.6	●	○			○									○	●		○	●		
	15mm 1/3.5	●	○			○									○	●		○	●		
	18mm 1/3.5	●	○			○									○	●		○	●		
	20mm 1/2.8	●	○			○									○	●		○	●		
	20mm 1/3.5	●	○			○									○	●		○	●		
	24mm 1/2	○	○			○		○					○		○	○		○	○	○	
	24mm 1/2.8	●	○			○		○					○		○	●		○	●		
	28mm 1/2	○	○			○		○					○		○	○		○	○	○	
	28mm 1/2.8	●	○			○		○					○		○	●		○	●		
	28mm 1/3.5	●	○			○		○					○		○	●		○	●		
	35mm 1/1.4	○	○			○		○					○		○	○		○	○	○	
	35mm 1/2	○	○			○		○					○		○	○		○	○	○	
	35mm 1/2.8	●	○			○		○					○		○	●		○	●		
Normal	50mm 1/1.2	○	○			○		○							○	○		○	○	○	
	50mm 1/1.4	○	○			○		○							○	○		○	○	○	
	50mm 1/1.8	○	○			○		○							○	○		○	○	○	
Telephoto	85mm 1/1.4	○	○			○		○							○	○		○	○	○	
	85mm 1/2	○	○			○		○							○	○		○	○	○	
	105mm 1/1.8	○	○			○		○							○	○		○	○	○	
	105mm 1/2.5	○	○	○	○	○		○					○		○	○		○	○	○	
	135mm 1/2	○	○			○		○					○		○	○		○	○	○	
	135mm 1/2.8	●	○			○		○				○	○		○	●		○	●		
	135mm 1/3.5	●	○			○		○					○		○	●		○	●		
	180mm 1/2.8 ED	●	○	○	○	○		○					○		○	●		○	●		
	200mm 1/2 IF-ED	○	○			○		○					○		○	○		○	○	○	
	200mm 1/4	●	○			○		○					○		○	●		○	●		
300mm 1/2 IF-ED	○	○			○		○					○		○	○		○	○	○		
400mm 1/2.8 IF-ED	○	○	○	○	○		○					○		○	○		○	○	○		
Zoom	28-50mm 1/3.5	●	○			○		○							○	●		○	●		
	28-85mm 1/3.5-4.5	●	○		○	○		○							○	●		○	●	○	
	35-70mm 1/3.5	●	○			○		○							○	●		○	●	○	
	35-70mm 1/3.3-4.5	●	○			○		○							○	●		○	●	○	
	35-105mm 1/3.5-4.5	●	○			○		○							○	●		○	●	○	
	35-135mm 1/3.5-4.5	●	○			○		○							○	●		○	●	○	
	35-200mm 1/3.5-4.5	●	○			○		○							○	●		○	●	○	
	50-300mm 1/4.5-ED	●	○			○		○							○	●		○	●	○	
	80-200mm 1/2.8-ED	●	○			○		○					○		○	●		○	●	○	
	80-200mm 1/4	●	○			○		○							○	●		○	●	○	
100-300mm 1/5.6	●	○			○		○							○	●		○	●	○		
200-400mm 1/4 ED	●	○			○		○							○	●		○	●	○		
AF (for F-501/N2020)	24mm 1/2.8	●	○			○		○				○			○	●		○	●		
	28mm 1/2.8	●	○			○		○				○			○	●		○	●		
	50mm 1/1.4	○	○			○		○				○			○	○		○	○	○	
	50mm 1/1.8	○	○			○		○				○			○	○		○	○	○	
	55mm 1/2.8 Micro	●	○			○		○				○			○	●		○	●	○	
	180mm 1/2.8 IF-ED	●	○	○	○	○		○					○		○	●		○	●	○	
	300mm 1/2.8 IF-ED	○	○	○	○	○		○					○		○	○		○	○	○	
	28-85mm 1/3.5-4.5 Zoom	●	○			○		○							○	●		○	●	○	
	35-70mm 1/3.3-4.5 Zoom	●	○			○		○							○	●		○	●	○	
	35-105mm 1/3.5-4.5 Zoom	●	○			○		○							○	●		○	●	○	
35-135mm 1/3.5-4.5 Zoom	●	○			○		○							○	●		○	●	○		
70-210mm 1/4 Zoom	○	○			○		○							○	○		○	○	○		
AF	80mm 1/2.8	●	○			○		○				○	○		○	●		○	●	○	
	200mm 1/3.5 F-ED	●	○			○		○							○	●		○	●	○	
Noct	58mm 1/1.2	○	○			○		○			○				○	○		○	○	○	
Micro	55mm 1/2.8	●	○			○		○				○			○	●		○	●	○	
	105mm 1/2.8	●	○			○		○				○			○	●		○	●	○	
Reflex	500mm 1/8	●	○			○		○							○	●		○	●	○	
	1000mm 1/11	●	○			○		○							○	●		○	●	○	
	2000mm 1/11	●	○			○		○							○	●		○	●	○	
Series E	28mm 1/2.8	●	○			○		○				○			○	●		○	●		
	35mm 1/2.5	○	○			○		○				○			○	○		○	○	○	
	50mm 1/1.8	○	○			○		○				○			○	○		○	○	○	
	100mm 1/2.8	●	○			○		○				○			○	●		○	●	○	
	135mm 1/2.8	○	○			○		○				○			○	○		○	○	○	
	36-72mm 1/3.5 Zoom	●	○			○		○							○	●		○	●	○	
	70-210mm 1/4 Zoom	○	○			○		○							○	○		○	○	○	
75-150mm 1/3.5 Zoom	●	○			○		○							○	●		○	●	○		

- = Excellent focusing
- = Acceptable focusing
Split-image rangefinder, microprism or cross-hair area is dim; focus on the surrounding matte area.
- = Acceptable focusing
Slight vignetting or moire phenomenon affects screen image, but film image shows no traces of this.
- = Exposure measurement via full-aperture method (AI-type camera only)
- = Exposure measurement via stop-down method

- = Exposure measurement is not possible; lens/screen combination permits focusing operation only.
- () = Indicates degree of exposure compensation. Blank means not usable.

When using Nikon AI camera bodies other than F3- and F2-series cameras (e.g., Nikon FA, FE2, FM2 and FE), refer to the F3-series chart. For the K2, B2 and E2 focusing screens, refer to the columns on the K, B and E screens. For details, also refer to your focusing screen's instruction manual.