


Modern Classic SLRs Series :
Canon F1 - Helper Page 2 (Back)

[FrontView](#) | [BackView](#) | [Lens Mount](#)



- 27. Meter Switch
- 28. Back Cover
- 29. Dioptric Adjustment Ring
- 30. Viewfinder Eyepiece
- 31. Tripod Socket
- 32. Back Cover/Film Chamber Attaching Guild Groove
- 33. Contacts for Controlling Motor Drive
- 34. Battery Compartment
- 35. Film Rewind Button
- 36. Film Winding Coupler for Motor Drive Uni
- 37. Bottom Cover Safety Stopper

| [Back](#) | [Next](#) |